



INSTRUCTION MANUAL
CUM
WARRANTY CARD

IMMERSION ROD WATER HEATER

AVAILABLE IN 1000W | 1500W | 2000W



ISO 9001	: 2015
ISO 14001	: 2015
OHSAS 18001	: 2007





Immersion Rod Water Heater

Congratulations!

You are now a proud owner of an energy efficient GP Prime Immersion Rod Water Heater - which are durable, dependable and safe for your family to use.

Important: Please read this instruction manual carefully before use. This instruction manual contains information as well as recommendations on the proper use of your Immersion Rod Water Heater and its maintenance. This Manual also contains your Warranty Card which needs to be preserved for future references.

INSTRUCTIONS

1. The immersion rod is provided with 3 core cable where Green is for Earth. It is imperative that the heater should be connected to a three pin socket with proper earthing. It is risky to use the heater without proper earthing.
2. The immersion rod should be connected to the main only after it is dipped in water.
3. The immersion rod should be immersed in water where the level will be in between the minimum and maximum level indicated on the strip. If the level of water is lower than the minimum level mark, it will result in burning of the element due to dry heat. And if the level of the water is higher than the maximum level mark, then there are high chances that the water will enter into the bakelite connector which will result in short-circuit.
4. The current should be switched and plug should be removed from the supply before taking the immersion rod out of the water.
5. Please keep the immersion rod in the water for a minute or two after switching off the current.
6. The immersion rod is meant for heating water only and is not recommended for use in other liquids such as milk, etc as to avoid any corrosion effect on immersion rod.
7. Do not bring the immersion rod near any combustible agent after its withdrawal from water.
8. Do not dip bakelite connector in the water.
9. The vessel should not be deep less than 175 mm and its shall be possible to hang the immersion rod with the help of the hook.
10. Use only metal vessels for proper earthing.
11. Bursted, dry ruined overheated or in running conditioned, mishandled piece will not bear any kind of warranty.

WARRANTY TERMS AND CONDITIONS

This appliance carries warranty for a period of one year from the date of purchase against defective material or manufacturing defect.

The warranty will not be valid if:-

1. Appliance is not used in accordance with the instruction as mention on the box.
2. Breakage, Burnt or damage of any is not considered in warranty.

Company will not be responsible for any delay in servicing due to non availability of any component or due to reasons beyond the control of the company.

WARRANTY CARD

Date Of Purchase ____ / ____ / ____

Product Name _____ Invoice No.: _____ Model No.: _____

Dealer's Name & Address _____

Customer Name & Address _____

Serial No.: _____

Ean Code: _____

Dealer's Stamp & Sign






GOLDEN PRIME TECHNOLOGIES

Marketed by:

REMAIN PRIME TECHNOLOGIES PVT LTD

+91 9700 800 900 | hello@goldenprime.co.in | www.goldenprime.in



Remain Prime reserves the right to amend or modify the specifications & features at any time, as & when required without any prior notification. Images displayed here may vary from the actual product. Features vary by products.