



COOKTOP
INSTRUCTION MANUAL
CUM
WARRANTY CARD



SAFETY



CM/L 8700013910

CE **RoHS**
COMPLIANT

ISO 9001 : 2015

ISO 14001 : 2015

OHSAS 18001 : 2007

Style
for your kitchen



COOKTOPS

Flare | Dazzle

Dear Customer,

Welcome to the world of Golden Prime Home Appliances.

This booklet will help you to understand and use your Cooktops properly. It gives you the required instructions on its operation and care.

PRECAUTIONS

- Do not use abrasive or corrosive products, chlorine-based cleaner or hard rubbing for built in.
- Do not allow children to use the appliance without supervision.
- In case of Glass Cooktop, please peel the protective film as it is inflammable.
- Please ensure that the cylinder knob is Off before cleaning the product

MAINTENANCE

How to clean the Burners of your Gas Stoves:

- The appliance has been purchased from the company's authorised dealer and is accompanied by warranty card/cash memo as a proof of Date of Purchase.
- The appliance has been not open/tempered /repaired by anyone other than our Authorized Service Centre.
- The appliance has been installed, used and maintained in accordance with the instruction manual.

How to clean the grids of the Gas Stoves

- Use a soft non-abrasive sponge or pad to clean the debris or grime/stain from the burner grids.
- In case of difficult stains, use Baking Soda paste to scrub away the stains.
- Rinse them with water and dry off them completely before placing them on the gas stoves.

How to clean the surface of Gas stoves

- Remove gas burner and grids from gas stove.
- Remove any debris/pieces being collected on the stove's surface.
- Spray the entire gas stovetop with glass cleaner or soap – warm water mixture.
- Use a sponge and scrub away any existing stains. Use a clean dry cloth to remove any excess cleaning solution.
- Replace the gas stove burner, grids to their original spots after finishing the cleaning.

WARRANTY TERMS AND CONDITIONS

WARRANTY IS VOID, IF

Abuse & Misuse: Defects or damage that results from:

- Improper operation, storage, misuse or abuse, accident or neglect, such as physical damage (cracks, scratches, rusts, breakage of glass, etc.) to the surface of the product resulting from misuse/storage.
- Contact with liquid, water, rain, extreme humidity or exposure to acidic atmosphere, sand, dirt or the like, extreme heat or food.
- Use of products for commercial purposes or at places like institution, hospitals, community halls, hotels, canteen, cafeteria's and other similar applications or subjecting the product or accessory to abnormal usage or conditions.
- Consumer using any kitchen utensils/cooking appliances/aids which cover the burners and touch the glass surface directly on the glass
- Any alterations made in product
- Scratches, breakages, unauthorized installations
- Damage due to misuse
- Discoloration of burners due to oxidation
- Usage of wrong detergents/chemicals for cleaning or any other purpose.

Altered Products:

- Serial numbers or date tags have been removed/altered
- Mismatched serial numbers

Accidents: accidents as result due to following reasons:

- Accidents caused due to non-maintenance of the product
- Accidents resulting from improper installation of the product
- Charcoal filters directly exposed to flame of cooktop.

WARRANTY CARD

Warranty on Product-2 years

Date Of Purchase ____ / ____ / ____

Product Name _____ Invoice No.: _____ Model No.: _____

Dealer's Name & Address _____

Customer Name & Address _____

Serial No.: _____

Ean Code: _____

Dealer's Stamp & Sign



GOLDEN PRIME TECHNOLOGIES

Marketed by:

REMAIN PRIME TECHNOLOGIES PVT LTD

+91 9700 800 900 | hello@goldenprime.co.in | www.goldenprime.in



Remain Prime reserves the right to amend or modify the specifications & features at any time, as & when required without any prior notification. Images displayed here may vary from the actual product. Features vary by products.